

ROBUST HIGH QUALITY FLOW MONITORS



MANUAL ELETTA STEAM







	Table of	Contents	3
		About this Manual	3
		Proprietary Rights	3
		Distributors	3
		Customer Service	3
1	Safety in	structions	4
2	General	informations	5
	2.1	Descriptions	6
	2.2	Product label	<u>7</u>
3	Base Uni	t Steam	<u> </u>
4	Pipe Sec	tion	<u> </u>
5	Control l	Jnit	<u> </u>
	5.1	Accuracy	10
	5.2	The Output Signal	11
	5.3	Control Unit options	11
6	User Inte	erface	14
	6.1	Product label	14
7	Specifica	itions	15
8	Certificat	tes	17
9	Ordering]	18
10	Installati	ion	19
	10.1	Unpacking	19
	10.2	Procedures before installation	19
	10.3	Installation of Pipe Section	19
	10.4	Connecting Pipe Section and Control Unit	21
	10.5	Installation and changing of Control Unit	22
	10.6	Electrical Installation	23
	10.7	Screen setup	26
11	Operatio	on differential pressure	31
	11.1	Principle of operation with DP	31
	11.2	Pressure drop	31
12	Change o	of Flow Range	33
13	Change o	of Flow Direction	35
14	Mainten	ance	36
15	Troubles	shooting	37
	15.1	Verification of flow	37
	15.2	Spare parts	38
16	Tables	- F F	39
	16.1	Differential Pressure Range 1-10	39
	16.2	Flow Ranges	39
	16.3	Weight and Dimensions	40
17	Drawing	S	44
	17.1	Eletta Steam	44
	17.2	GSS/FSS	46
18	Recyclin	a	47
		J	



About this Manual

- This manual relates to Eletta Steam. It consists of Base Unit Steam, Control Unit and User Interface. Only sold with FSS or GSS Pipe Section.
- Note that the latest version of this manual and other documents are always available as a PDF file on web site <u>www.eletta.com</u>

Proprietary Rights

This manual contains confidential technical data, including business and property rights, which are the property of Eletta Flow AB, Sweden.

Any changes or alterations to downloaded or printed Eletta original documentation such as manuals, drawings, leaflets, newsletters, etc. are prohibited without a written permission from Eletta Flow AB, Sweden.

This data is only disclosed under permission of limited use within costumer company. Any other use of data and information is strictly prohibited without prior written permission from Eletta Flow AB, Sweden.

Distributors

Eletta has authorized distributors all over the world. More information about the closest distributor is on web site <u>www.eletta.com</u> or by contacting Eletta Customer Service Center.



1. Safety instructions



1.1 Safety instructions

- In this manual, this warning symbol is used to emphasize where particular care must be taken to avoid injury or damaging the product.
- The Control Unit and User Interface must not be installed in explosive enwvironments.
- To prevent injury when installing the Control Unit, make sure that the system is not pressurized from gas or liquid flow.



- There are no serviceable parts inside the instruments. Eletta takes no responsibility for injury or damage caused by unauthorized disassembly.
- Never remove the Control Unit while the system is pressurized.
- The electrical installation must only be done by authorized personnel.
- Disconnect all power connections before installation or service.
- Never exceed the maximum static pressure, which is specified on the product label, and in this manual.
- Make sure that the correct electrical power is used.
- Always make sure the condensate pots are filled at system startup.
- If connection nipples eller compression couplings are used for the threaded Pipe Section, (GSS) the inner diameter must not be smaller than pipe inner diameter: GSS 15 = 16 mm GSS 20 = 21 mm GSS 25 = 26 mm

2. General information



2.1 **Description**

Eletta Flow Monitors are used to control and measure flow of liquids, and gases in pipes from size 15 mm to 500 mm (larger pipes as an option). They have been manufactured for over 70 years and are well known for their reliability. They are used where operational safety demands, efficient supervision and rugged installation is needed.

All over the world. Eletta Flow AB in Sweden is certified according to ISO9001 and ISO14001. The Eletta Flow Monitors are based on the proven and dependable differential pressure principle, using interchangeable orifice plates for different measuring ranges. Due to the working principle of the instrument, it is of utmost importance that the installation instructions (See section **10"Installation"**) are followed carefully in order to get the proper function of the instrument.

Eletta Steam is used for measuring mass flow of saturated steam.

Eletta Steam consists of four parts mainly:





2.1 **Description**





2.2 Product label

Each Eletta Steam has two identical product labels, see **Fig. 1** with description. One is placed on Base Unit Steam, the other on Control Unit

E	Phone	FLOW CONDITIONS		
Type: Eletta Steam-FSS50		Ambient Temp: -15 to 90°C		
Model:	283024050	Max Pressure: 10 Bar	Fluid: Steam	
Supply:	8-28 Vdc	Protection IP67 Class:	Pressure: 5 bar (g)	
Output:	4-20 mA		Q: 40-400 kg/h	
No:	XXXXXX		Δ p Range: 5-500 mbar	

Fig. 1

- **Type:** Product type Eletta Steam and Pipe Section.
- Model: The article number of Eletta Steam.
- Supply: External supplied voltage for Control Unit
- **Output:** Output signal from Control Unit
- No: Serial number of Eletta Steam. Each Eletta product has their own unique ID-number, which is used for traceability.
- **Ambient Temp:** Surrounding temperature range. See section **7 Specifications** for a thorough description of available types.
- Max Pressure: The maximum operation pressure allowed for the flow monitor.
- Protection class: IP-classification (International protection rating), of the Control Unit.
- CE-marking and Year of manufacturing.
- Fluid: The media which the flow monitor has been designated for. E.g., Steam.
- **Pressure:** The maximum operation pressure allowed for the flow monitor.
- Range Q: The flow range for which the flow monitor has been manufactured.
- Δp Range: Differential pressure range

Function		Female connector	Wire color	
8 - 28 +		Pole 1	WHITE	
VDC	-	Pole 2	BROWN	
RS485A		Pole 3	GREEN	
RS485B		Pole 4	YELLOW	
Not active		Pole 5	GREY	
Not active		Pole 6	PINK	
Not active		Pole 7	BLUE	
Not active		Pole 8	RED	



On the Control Unit's cable at the open end, there is a sticker with the wiring diagram



The Base Unit Steam connects the two channels with different pressure from the Pipe Section to the Control Unit. The steam transfers its pressure through the water in the condensate pots to the sensors in the Control unit. For each pressure channel, there are deaeration valves both before and after the condensate pots. Air vents and shut-off valves will allow discharge of any entrapped air/gas or condensate and also provide the possibility to even out the pressure between the plus and minus leg for zero-level verification. The mounting plate allows the Base Unit Steam to be placed at any place convenient for operators.

The pots must always contain water when the system is operating. The sealings in condensate pots and fittings must be checked on a regular basis.

4. Pipe Section

The Pipe Section is the part that is to be mounted in the process pipe. It is connected to the Steam Unit with metal pipes. The connecting block includes one shut-off valve per channel. It enables dismounting the Control Unit from the Pipe Section during full operation.

The Pipe Sections in stainless steel 316L are available in different dimensions:

- **FSS:** DN15-DN500 for DIN max PN16 DN15-DN500 1/2"-18" for ANSI max 150 lbs
- **GSS:** DN15-25 with BSP or NPT threads





The Control Unit M-series is used to measure DP and control flows of steam, liquids and gases in threaded pipes with sizes DN15-DN25 and flange fitted pipe sizes DN15 to DN500.

When ordered, Eletta Steam will be delivered with the Control Unit mounted on the Base Unit Steam. The Control Unit is programmed, tested and calibrated at Eletta production site and ready to connect to the Pipe Section, no on-site adjustments or calibrations are needed. At the time of order, data for the steam application is used for configuration of the unit. This enables quick and easy installation by the user. Only mechanical assembly and electrical installation are needed. No further adjustments have to be done by the user. The Control Unit connected with cable to the User Interface.

However, it is possible to adjust most parameters in the field after installation using the Eletta Flow Center or Modbus RTU. More information about this can be found in the manual of Eletta Flow Center.

The viewing settings on optional display version can be changed directly on the Control Unit but will not affect the Control Unit other settings.

For more information, see chapter **5.4 Control Unit options.**

The Control Unit contains the two pressure sensors, a circuit board and an electrical connector with integrated filter. The circuit board outputs 4-20 mA and Modbus RTU through the output connector. The settings are adjustable using Flow Center or Modbus. Settings for the optional display can be changed directly at the meter but will not change the measurements.



In order to get the unit to work properly with good accuracy, it is very important that the unit is installed correctly according to the installation instruction, see chapter **10.5 Installation and changing of Control unit.**



5.1 Accuracy

The M-series Flow Meter measures media pressure using two independent pressure transducers. The measured values are then converted to a flow value by the microprocessor. The flow accuracy can be separated into:

- The M-series pressure sensors have an accuracy of +/-0,05% F.S.(Full Scale) of the measured differential pressure.
- The orifices are calculated according to ISO 5167. The measurement error, related to the orifice calculation, varies because it depends on the type of media, flow conditions and pipe dimension. At ideal conditions an accuracy within 0,5-1% FS of the calculated flow can be expected.
- Tolerances in Pipe Section and orifice bore diameter contribute to around 0,5-1% FS.

Display option: The 4-20mA signal and Modbus RTU accuracies are unchanged. The displayed value will not differ from the output during normal use but can differ up to 4.5% during high power EMC interference.

5.2 The Output Signal

Each orifice plate is designed and optimized for a specific flow range and fluid. This means that there is a maximum flow value for a specific orifice plate. This value is represented by the flow percentage 100%. A flow value higher than the maximum flow value will not be measured with the same accuracy.

The analogue output signal from the Control Unit is always in the range 4-20 mA as default. This means that the maximum flow (100%), for a specific orifice plate, corresponds to the output level 20 mA. However, the minimum flow 0% is merely theoretical since it is not possible to use the differential pressure principle if there is no flow at all. There has to be a certain minimum flow to create the different pressures on the upstream and downstream side of the orifice plate. Therefore, the Flow Meter is said to have a turn down of 1:10. In this very case, the lowest flow must be 10% of the maximum flow in order for the Flow Meter to be able to work properly.



For more information about the behavior of the output signal, see the Flow Center manual.

5.2.1 Customized range

Using the software Flow Center (can be downloaded from Eletta web site), it is possible to let the output signal range limits correspond to other values than 0% and 100 % flow. In this way, if the application always has a flow of 40-60%, it can be "zoomed in" on this range and let 4 mA correspond to 40% flow, and 20 mA correspond to 60% flow.

5.3 Control Unit options

5.3.1 Cover in stainless steel

The cover of the Control Unit is manufactured in Polyamid plastic; PA12 (Grillamid 1kn-5h). It is known to be chemical resistant to most common fluids for which the M-series is used. But in rare cases with even tougher environments M-series is also available with a stainless steel cover as an option. EN 1.4436 (grade 316) Stainless steel cover cannot be combined with a display.



5.3.2 Control Unit display

Loop powered display of OLED 128*32 pixels to show flow rate, flow total and 4-20 mA analog output value. This option is not available for Stainless cover.

The Control Unit with display has three display modes that are cycled by pressing the green centre button. The up and down arrows are exclusively for changing settings of the meter and are not needed during normal operation.

The totalized view displays the total Qa% of steam that has passed the unit.



Qa percentage measured flow of Qmax



4-20mA

5.3.3 Changing the display settings

The Control Unit's settings are independent from the values sent through Modbus RTU and Flow Center.

Press the up and down arrow down simultaneously for 5 seconds until the display changes to display "Rst total", this indicates that the meter is in "settings mode".

The meter has five menu entries;

- Rst Total
- Rotate 180
- Unit Select
- Set Qmax
- Return.

The menu entries are cycled by pressing the up or down arrow and selected by pressing the green button.

Rst total

Pressing the green button will reset the volume of the logged flow to zero.



Rotate 180

Pressing the green button will rotate the screen 180° (Flip it horizontally) The buttons will automatically adjust for the viewing angle.



Unit select

Pressing the green button will bring up the unit submenu. Cycle through the different unit options by pressing the up or down arrow and selecting the wanted unit by pressing the green button. Available units of measurement: LPM, CMH, LPS, CFM, CFH and %. Other units may be available on request.

Set Qmax

The Set Qmax menu is used to set the maximum flow value which is the same maximum value set in Flow Center. Each number is increased by pressing the up arrow and decreased by pressing the down arrow. Pressing the green button will select the shown value. The chosen number will shift to the left by one for each press of the green button. Leave a value blank or a zero if no such high numbers are required. This is only used when recalibrating the display.

Return

Pressing the green button in the Return menu will bring back the main menu, showing the current flow.

5.3.4 Communication cable for Control Unit

The Control Unit is always configured according to order information when delivered from the factory. Eletta Flow Center is available for download on Eletta website together with the required drivers for the communication cable. The Communication cable is not included with the purchase of the Control Unit, it is sold separately as an option.

An external power source has to be used in order to provide enough power to the unit with display. This is done through a 2,1x5,5 mm DC plug barrel connector on the side of the communication cable. This is only mandatory for the Control Unit with display.

Interface converter with Binder socket 713/8-pin:

- Supply via USB for one connected final consumer.
- Visual status and configuration display (LED)
- Galvanic isolation
- Total length: 1,7 m
- External supply voltage: 18-20VDC





_100.0

-



FI F1



The User Interface connected with cable to the Control Unit.

Description

The User Interface is an HMI screen that designed and specially programmed to interfere with Eletta M-series for the steam applications and measurements. User Interface powers the M-series and communicate with it via Modbus RS485.

The displayed values on the screen that have been calculated by the User Interface according to the steam table formula are:

Q is the measured flow.

Q TOTALIZED is the measured flow totalizer.

Qc is the compensated measured mass flow.

Qc TOTALIZED is the compensated measured mass flow totalizer.

Qa is the percentage measured flow of Q max sent from the Control Unit.

Pa is the static pressure sent from the Control Unit.

H2O T Sensor is the Temperature of the water in condensation containers sent from the Control Unit.

The User Interface has the possibility to log the measured data internally to the internal memory of 50MB or to an attached SD card up to 4GB memory size which will be used to save logged data instead of the internal memory. It can also upload the logged data to an external USB flash drive that can be attached to the USB socket on the side of the User Interface box.

Note:

It is not possible to upload logged data to an USB flash drive if a SD card is attached, because the logged data will be saved on the SD card. To access the saved .csv file that has been saved on the SD card then the card needs to be removed and connected to a PC.

6.1 **Product label**

	ELETTA	
Туре:	User Interface	—
Model:	40-91130	—
Supply:	100-240 VAC, 50/60 Hz	—
P class:	IP65	—
No:	XXXXXXXXXXXX	
Phone +46(www.eletta	(8) 603 07 70 L.com CE 20	۲ ۹ 24
Type:	Product type User Interface	
• Model: Part number		
Supp	ly: External supplied voltage Us	er Interface
IP cla	I protection rating), of the User Interface.	
No:	Serial number of User Interfa	ce. Each Eletta product has their own uniq
	number, which is used for	traceability

• CE-marking and Year of manufacturing.



Specifications

Flow range	Steam: will be calculated according to application		
Flow measuring range (Turn Down)	 Turn down of 1:10 for Steam applications. M310, with standard pressure operating range of 5 – 500 mbar M325, with standard pressure operating range of 12,5 – 1250 mbar M350, with standard pressure operating range of 25 – 2500 mbar 		
Accuracy	+/-0,5-1% FS of the default differential pressure at reference con- ditions. (M310: 500 mbar, M325: 1250 mbar, M350: 2500 mbar) Display option : The 4-20mA signal and Modbus RTU accura- cies are unchanged. The displayed value will not differ from the output during normal use but can differ up to 4.5% during high power EMC interference. Totalizer has an accuracy of +/- 5%		
Pressure class	PN16 / ANSI 150 lbs		
Max static pressure	 M310: 10 bar(g) (145 PSI) M325: 25 bar(g) only for threaded pipes GSS15-25. FSS pipes 16 bar(g). M350: 50 bar(g) only for threaded pipes GSS15-25. FSS pipes 16 bar(g). 		
Max over pressure	+ 50 % of Max static pressure		
Pressure endurance	10 ⁷ pressure cycles from 0 to F.S. at 25° C		
Protection class	IP67 (NEMA6) Control Unit IP65 User Interface		
Temperature ranges	Ambient temp: -15 to 90°C (-5 to 194°F) Ambient temp M-Display option: -10°C to +70°C (+14°F to 158°F) Ambient temp User Interface: 0-60°C (32-140°F) Pipe Section: -10°C to +230°C (+14°F to 446°F)		
Power supply	User Interface: 100-240 VAC, 50/60 Hz Control Unit: *Standard option: +8 VDC to +28 VDC (2 wire loop feed) *Display option: +18 VDC to +28 VDC (2 wire loop feed)		
Output	RS485 for external communication		



Materials

O-rings	FPM (Fluorinated rubber)			
Control unit	 Plate: Stainless steel 316L. Cover: Plastic PA12 Grilamid Ikn-5h. EMC shielding inside Option: Stainless steel EN 1.4436 Connector: 8-poles LTW 			
Connection cable	PUR Standard cable 2,5 m (10 m cable available as option) 8 x 0,25 mm2			
Pipe Section	Stainless steel 316L			
Orifice plate	Stainless steel 316L			
Base Unit Steam	Stainless steel 316L			
User Interface enclosure	ABS (UV Resistant)			

User Interface HMI Touch screen:

Screen size:	4.3 inch 16:9 aspect ratio.
Resolution:	480 x 272 pixels
Touch:	Analog resistive
Memory:	50 MB internal memory for logging. Possibility of connecting a maxi
	mum 4 GB SD card. USB socket to upload log file to a USB flash drive.

User Interface enclosure:

Mounting:	Wall mounting
Electrical insulation:	Totally insulated
Flammability rating:	UL 94 HB



CE and UKCA approvals:

Eletta Flow Meters conform with the following EU directives:

M-series Flow monitors comply with the EMC directive 2004/108/EC through the following harmonized standards:

- EN 61 000 6 3:2007 Generic Emission Residential, commercial and light industry.
- EN 61 000 6 2:2005 Generic Immunity Industry
- M-series Flow monitors with display comply with the EMC directive EN/IEC 61000-6-2:2019 and EN/IEC 61000-6-3:2007+A1 through the following harmonized standards:
- EN/(IEC) 61000-4-2:2009. Immunity to electrostatic discharges.
- EN/(IEC) 61000-4-3:2020. Immunity to radio frequency electromagnetic fields.
- EN/(IEC) 61000-4-4:2012. Immunity to fast transients.
- EN/(IEC) 61000-4-5:2014+A1. Immunity to surge transients.
- EN/(IEC) 61000-4-6:2014. Immunity to conducted radio frequency disturbances.
- CISPR 16-2-3:2016. Measurement of radio frequency electromagnetic field.

- Low voltage. 2014/35/EU

- For electromagnetic compatibility, EMC directive 2004/108/EC (EN 61 000 – 6 – 3:2007 and EN 61 000 – 6 - 2:2005)

- Electrical Safety regulation 2016

User Interface comply with CE, UKCA, UL (Class 1 Div.2)

PED-Directive:

Complies with applicable parts in Pressure Equipment Directive 2014/68/EU. Conformity assessment has been performed according to module A. Internal production control combined with module A2. Internal manufacturing checks with monitoring of the final assessment, for category 2. Performed by Kiwa Inspecta AB. PED Declaration of conformity will be supplied upon request. They are also available on <u>www.eletta.com</u>

9. Ordering



To specify when ordering Eletta Steam:

- 1. Flow ton/h
- 2. Pressure bar
- 3. Pipe type: FSS or GSS
- 4. Pipe dimension and standard DIN or ANSI
- 5. Type of Control Unit
- 6. Media temperature, if possible, to confirm
- 7. Option: straight Ø6mm SS pipe for connecting Pipe Section and Base Unit Steam. Specify length.
- 8. Flow direction alternatives at the Control Unit:



Example: Eletta Steam FSS, Control Unit with display, plastic cover, dimension: DN200 ANSI, range. 4–40 ton/h, 10 bar(g), installation. B/L.



10.1 Unpacking

Compare the delivered products to the Packing List. Make sure to check the box for external damage before opening. If damage of the packing material has damaged the Eletta Steam inside; contact the delivery company to claim replacement or economical compensation. Compare the product labels to the purchase order.

The packaging material is made from recycled, environmentally friendly material and can be re-used or recycled to have as little impact to the environment as possible.

10.2 Procedures before installation

- Check if the planned flow direction in the system matches the one indicated on the Control Unit. There is a red flow direction arrow on the Pipe Section, Control Unit's connection block and an arrow on the casted plate.
 If there is a mismatch; see section 13 "Change of Flow Direction"
- 2. Check that the Pipe Section has correct threading or correct flange dimension to match piping or counter flange. Bend \emptyset 6mm stainless steel pipes to connect the Pipe Section with the Base Unit Steam. It is mandatory that the pipes have equal length \pm 2mm.

10.3 Installation of Pipe Section

Note: Before any installation or maintenance work, disconnect all electrical power. Check that the system is empty, unpressurized and cool.

The direction-arrow on the Pipe Section indicates the direction of the flow. It is particularly important that the Pipe Section is mounted with the condensate hole on the orifice plate at the lowest position to avoid water-hammer. The

piping shall be rigid and free from vibrations.

As tubing will lead the pressure to the Control Unit, it is possible to mount the Pipe Section vertically or horizontally with the pressure ports pointing up or to the side. It is recommended to have the pressure channels directed upwards.

The straight pipe-runs before and after the Pipe Section should not be too short to avoid disturbances, which can cause incorrect values. It is recommended to allow at least 15 pipe diameters upstream and 5 pipe diameters downstream. The straight runs must be free from valves, bends, or changes in pipe diameters.





Recommended installation of Pipe Section



It is difficult to predict when the flow is stable after disturbances in the piping, so these recommendations serve as a guideline only.

The following inside diameters apply for the threaded Pipe Sections:

GSS 15 =	16 mm
GSS 20 =	21 mm
GSS 25 =	26 mm

Consider using a filter in the pipeline if the steam may contain particles.

The flanged FSS-versions must be aligned with the counter flange and the bolts must be tightened evenly. Flange-gaskets are included in the delivery, and it is recommended to use these, as they are dimensioned to suit the installation. Make sure the gaskets are properly aligned to not disturb the flow. It is also of utmost importance that the connecting pipe and flange have the same inside diameter and standard as the Pipe Section. A mismatch can cause incorrect readings of the flow.



10.4 Connecting Pipe Section and Control Unit

There is no actual limitation in the length of the tubing, but it is recommended to place the units as close to each other as possible to make troubleshooting easier.

Note: The hoses/tubing must have the same length to avoid uneven pressure. ± 2mm

Find a suitable place for the Steam Unit to be mounted. Attach the supplied plate to a wall, pipe, or another rigid support. Place it with respect to surrounding piping and obstacles. The condensate pots must be in upright position, see pictures.

Install the tubing starting at the Pipe Section. Check that there is enough length to cover the distance between the Pipe Section and Base Unit Steam. Press the tube ends into the couplings and tighten with care. Proceed to the Control Unit and repeat the step.

Before start-up it is important to fill the condensate pots with water. Make sure that all entrapped air in the piping between the Pipe Section and Control Unit is removed. Open the air valves until some water leaks. The air can otherwise, as it is a compressible media, cause faulty Flow readings.





10.5 Installation and changing of Control Unit

As all Eletta Flow Monitors are designed in segments to achieve a modular, versatile Flow Monitor, there is a possibility to upgrade/rebuild them and adding other features to the already installed Monitor, by changing the Control Unit or Pipe Section.

All Eletta DP Flow Monitors are working with the same differential pressure within their specific range (See section **2.1 "Description"**). If changing Control Unit make sure the settings is for steam.

- 1. Close the shut-off valves.
- Let the Base Unit Steam cool down. Turn the electric power supply off and then disconnect the cables from the User Interface and Control Unit.
- 3. Loosen the four (4) Allen screws that hold the Control Unit and replace the Flow direction selector sealing, if necessary. Install the new Control Unit and tighten the four (4) screws firmly again.
- Connect the electrical cables according to the new Control Unit's specification. For detailed information regarding wiring, see section 10.6"Electricalinstallation".
- 5. Before starting check that there is water in the condensate pots and deaerate.





10.6 Electrical Installation

Note Only authorized personnel should make all electrical installations. Before any circuit is connected/disconnected, make sure that all power is off

Before any cables are connected, make sure that the correct power supply is used (see section **7 "Specifications"**).

10.6.1 User Interface

Do not install the User Interface in Ex-hazardous areas.

10.6.2 Mounting the interface enclosure

Determine the mounting location by considering the enclosure specifications and the purpose of the User Interface unit. Ensure that the box is easily accessible and convenient for its intended use. It is also important to check local building codes and regulations to ensure compliance and safety. The enclosure is to be wall mounted by 4 screws.

10.6.3 Wiring and electrical installation

10.6.4 **Power supply connection through cable gland.**

Connect the power supply main lines L & N according to the wiring diagram shown in **Diagram 1** and Wiring description in **Table 2.**.



10.6.5 Electrical Installation

Connecting the M-series wiring **DC24**, **DC0**, **A**+ and **B**- to the User Interface according to the wiring diagram shown in **Diagram 2** and Wiring description in **Table 2**.



Diagram 1 Wiring diagram





Diagram 2 Wiring diagram

Function	User Interface	Control Unit (wire color)
+	DC24V	WHITE
-	DC0V	BROWN
RS485A	A+	GREEN
RS485B	В-	YELLOW
AC Line	L	-
AC Neutral	Ν	-
RS232 TX	ТХ	-
RS232 RX	RX	-
S485/RS232 GND	GND	-

Table 2 Wiring description



10.7 Screen setup.

- **Q max**: maximum flow value
- **UoM**: Unit of measurement
- **Td**: reference temperature
- **Pd**: reference pressure
- Q:
- **Q totalizer**: measured flow totalizer
- Qc: compensated measured flow value
 - **Qc totalizer**: compensated measured flow totalizer

measured flow value

- Qa: percentage measured flow of Q max
- **Pa**: static pressure
- **H2OT**: Temperature of the water in condensation pots/containers.



- 1. Unit of measurement: touch to type UoM
- 2. Maximum flow measurement: touch to type Q Max
- **3.** Calculation reference: touch to switch between inputting reference pressure(Pd) or reference temperature(Td).
- 4. Calculation reference value: touch to type the value of reference Pd/Td
- **5.** Time-unit of UoM: touch to choose between seconds, minutes, or hours.
- **6.** Logging: touch to start or stop logging.
- 7. Log upload: touch to upload the logging file to a USB flash drive.
- 8. USB eject: touch to eject the USB flash drive before removal.
- **9.** Log: touch to open logging screen.
- **10.** Q reset: touch to reset the measured flow totalizer.
- **11.** Qc reset: touch to reset the compensated measured flow totalizer.



Screen setup.

The arrows pointing to interaction touch points on the screen. By touching one of the pointed areas, it will activate a graphical button or bring up a keypad to modify or type a value or a parameter.



Image 2: Keypad screen to modify or type values.



Image 3: Graphical logging diagram.



18:	:00:28	3	08/03/24		ELET	TA	FLOW (M-MODBUS)
Sr.	Dat	Ti	FM01_p	FM01_Flo	FM01_Total	Qc	Qc_Totalizer	
M	ODB	US	LO	G-CLEAN	GRA	PH	SYS	TEM MENU

Screen setup.

Screen Operating

Image 4: Logging chart.

- A. Power up the User Interface by connecting the main power lines.
- B. Setup the screen to start measuring:
- I. Touch 1. to type the UoM.
- II. Touch 2. to type the Q Max.
- III. Touch 4. to type the reference value (Td/Pd).
- IV. Touch 5. to choose the Time-unit.





10.7.1 Measuring

The User Interface receives three values from the Control Unit. They are shown on the left side of the main screen. These are Qa as flow in %, Pa as static Pressure in bar, and H2O T in °C at Sensors as Temperature of water from condensate pots and impulse tubing that is touching the Control Unit sensors. (This is not the Steam's temperature, but as a safety display if the condensate pots get too dried up its water temperature will rise close to 100°C, which is the sensor's limit).

On the right side, the main screen displays the calculated values, starting from Q the flow value as a scaling of Qa to the Q-Max, the totalization for the same. Then the Qc as Flow Compensated for Pressure and Temperature variations against the Design Pressure and Temperature, and the totalization thereof.

10.7.2 **Logging**

Logging can be switched on or off for logging for Pa, Q, QT, Qc, QcT every second. The Log can be uploaded to a USB flash drive if no SD-card inserted. Log can also be viewed on the log screen as table or as a graph of differences between Q and Qc.

10.7.3 External communication

The User Interface can simultaneously act like a Modbus slave yielding Modbus outputs and all logged values here are available as online Modbus outputs with registers as below:

COM 1 Baud Rate: 9600 Parity: None Data Bit: 8 Stop Bit: 1 Node Address: "1".

Real Type Data for: Pressure, Pa: 400001 Flow Measured, Q: 400003 Flow Total, QT: 400005 Flow Compensated, Qc: 400007 Qc Total, QcT: 400009



10.7.4 **Control Unit** Do not install the Control Unit in Ex-hazardous areas

The connection cable is included in the purchase of the Control Unit. The cable has eight wires and a M12-female connector with screw locking and one end open. The standard cable length is 2,5 m. A 10-meter cable is available as an option.

In the case splicing the cable in order to extend the cable further than 10 meters, make sure that the conductive area of the wires for the output signal is at least 0,25 mm2 (0,00039 inch2). Maximum output load is $1k\Omega$.

Make sure that the correct power supply is used, the allowed voltage range is between +8 to +28 VDC.

A wiring diagram is attached on the cable at delivery.

Wiring connection for the M12 M3XX unit. The configuration is referenced looking at the female of the cable connecting to M unit.



Functi	on	Female connector	Wire color			
8 - 28	+	Pole 1	WHITE			
VDC -		Pole 2	BROWN			
RS485	A	Pole 3	GREEN			
RS485	В	Pole 4	YELLOW			
Not ac	tive	Pole 5	GREY			
Not active		Pole 6	PINK			
Not active		Pole 7	BLUE			
Not active		Pole 8	RED			



M12 - 8 pin

11 Operation differential pressure



11.1 Principle of operation with DP

The function of the Eletta Flow Meters and Monitors is based on the proven and dependable differential pressure principle. The instruments use interchangeable sharp-edged orifice plates designed for different measurement ranges.

This is probably one of the oldest and most widely used principles for flow measurements. The principal benefits from simplicity and low cost. In addition, it exists a large amount of research data and experience, which is useful when predicting the behaviour of a certain orifice plate.

Inserted into the Pipe Section, the orifice plate constitutes an area restriction that causes a pressure drop after the orifice plate. This pressure drop varies with the flow rate. It means that in the flow direction, there is one pressure before the orifice plate, and another after the plate. The first pressure will be slightly higher than the second.

The two pressures, before and after the orifice plate, are lead through two separate channels to separate pressure sensors in the Control Unit. The two pressures are measured and the difference is calculated. This is called differential pressure.

The flow (Q) and the differential pressure (ΔP) are proportional to each other. The relation can be approximated by the formula Q = $\sqrt{\Delta P}$

11.2 Pressure drop

Since the Eletta Flow Meter is based on the Differential Pressure Principle, it is inevitable that a small permanent system pressure drop is caused. The reason is that the orifice plate reduces the flow area inside the pipe, and this will affect the pressure.

It is important to fully understand two types of pressure drops. The first is the actual pressure drop created between both sides of the orifice plate. The second is the permanent pressure drop that will slightly affect the system.

The actual pressure drop is a temporary state that occur over the orifice plate. On the downstream side of the Pipe Section the pressure will try go get back to the same conditions as on the upstream side. Normally, the flow profile will be recovered on the downstream side after approximately 10-15 times the inner diameter of the pipe. However, due to friction losses caused by the orifice plate, the system pressure will be somewhat less on the downstream side. The size of this loss, the permanent pressure drop, can be calculated using two mathematical formulas.



The **permanent pressure drop** can be calculated approximately by:

Δρ (p) =	Δρ (a)•(1-β²)
Δρ(p) =	Permanent pressure loss
Δρ(a) =	Actual pressure loss for a certain flow
Δρ =	Differential pressure flow measurement
β =	d/D ratio (ratio between bore and inner diameter of the pipe)

Within the normal β range (0.2-0.7) a typical permanent pressure loss range 0.96 $\Delta\rho$ - 0.51 $\Delta\rho$ can be expected.

The **actual pressure drop** can be calculated approximately by:

Δρ(a)=	(Q/Qmax) ² xΔρ(max)
Δρ(a)=	actual pressure loss
$\Delta \rho(max) =$	maximum allowed differential pressure, see "Flow conditions" on the label.
Q =	actual flow
Qmax =	maximum flow for the orifice plate, see "Flow conditions" on the label.

Example:

Assuming the following:	
Q range:	0-10 l/min
Q =	5 l/min
d =	5,9 mm
D=	16.0 mm
Media pressure =	5 bar
$\Delta \rho(max) =$	500 mbar
This gives a β of 5,9/16.0=	0,36875,
which results in $(1-\beta^2) =$	0,864
Hence, $\Delta \rho(p) =$	Δρ(a)x 0,864



A flow of 5 l/min results in an actual pressure drop of $(5/10)2 \times 500 = 125$ mbar.

The curve below approximately shows the relation between the actual pressure loss and the flow percentage.

The permanent pressure drop will then be 0,864*125=108 mbar If this drop is compared to the system media pressure of 5 bar, it is found that the efficiency η is almost 98%.

 $\eta = (5-0,108)/5 = 97,8\%$

This means that mounting a Flow Meter with a bore, that temporarily decreases the flow area with as much as 86%, only decreases the static pressure with approximately 2 % at 50% flow.



The Eletta Flow Monitor features an orifice construction that does not require recalibration after replacement and can easily be rebuilt in-field to change the flow range to another from the flow rate ordered. This is valid for all Pipe Sections.

If another flow range than ordered originally is needed; the orifice plate inside the Pipe Section is the only part that has to be changed. Any flow range that suits the specific application can be ordered, as long as the new flow rate is within the possible span for the Control Unit's dimension (see table in section **16.2"Flow ranges"**)

In each case of rebuilding the flow Monitor on-site, consult Eletta or a local Distributor for advice of the correct orifice plate before ordering.

Empty the piping system so it is not pressurized and has no flow. Let it cool.

Threaded model: GSS



3.

Take out the spacer that holds the orifice plate. Change the orifice plate. **It is of utmost importance that the hole for condensate is at the lowest point.**

4.

Change the o-ring if necessary.

5.

Reinstall the spacer that holds the orifice in place in the Pipe Section. Install the Pipe Section in the piping system and tighten the bolts firmly to avoid leakage.





Flanged model -FSS



Type plate

When changing the orifice label, to get a new flow range, it is recommended to change the identification plate to the one with the new range marked. This identification plate is delivered with the orifice plate when ordering an orifice plate separately. Make sure that output signals in the receiving end PLC, display, User Interface computer etc., are matched for the new flow range.



At the time of ordering, the flow direction is specified and decides how Eletta Steam shall be mounted, i.e. from which side the media enters the Pipe Section. (See **Fig. 10** for alternatives.) If, for some reason, Eletta Steam is ordered with the wrong flow direction or the production process is altered, it is possible to change this on-site.

- 1. Close the shut-off valves, disconnect the cables and let the system cool down.
- 2. Remove the four (4) Allen screws, which attach the Control Unit to the Base Unit Steam. (See **fig. 10** below)
- 3. Replace the sealing if necessary
- 4. Turn the Control Unit 180°.
- 5. Change the direction of the arrows on the Pipe Section and on the Control Unit. (See **fig. 11** below)
- 6. Fasten the four (4) Allen screws.









Inspect the orifice plate on a regular basis. Check for damage, dirt build-up and that the edge of the orifice plate is still sharp. The sharp edge of the bore is crucial to provide proper and accurate flow reading. If the bore wear is excessive, please contact a local distributor or Eletta Flow for purchase of a replacement orifice.

- Inspect the condensate pots and clean them. Fill them before starting up the system again.
- Inspect the power and output wirings for signs of corrosion, cracks or deterioration. Check that the electrical connector to the instrument is tightly attached and shows no signs of corrosion.
- Inspect the process pipe body and connections for signs of corrosion and fatigue fractures.
- Make sure the Flow Meter isn't exposed to vibrations.
- Check that the temperature at the Control Unit doesn't exceed the max temp of 100° C.
- Inspecto-ringsand sealings. Replace them if necessary, new ones can be ordered from Eletta distributors or directly from Eletta. See section 17.1 Drawings Eletta Steam

6	O-ring FPM Order specific	FPM	1
5	Flow direction selector FPM	FPM/316L (1.4404)	1
4	O-ring 8x1 FPM	FPM	1
3	O-ring 8.1x1.6 FPM	FPM	1
2	O-ring 7.3x2.4 FPM	FPM	1
1	O-ring 29.2x3 FPM	FPM	1
ITEM NO.	DESCRIPTION	MATERIAL	QTY.



15.1

Verification of flow

All Eletta Control Units are calibrated and adjusted individually with water in a dedicated calibrated flow rig under reference conditions with enough straight runs before and after. If the Control Unit shows another value compared to a reference meter on site, it can be due to that the reference meter has been calibrated under other reference conditions and that the Control Unit have other conditions on site in the actual application, than used during the calibration prior to shipping. The accuracy stated is achievable only if the instrument is correctly installed according to this manual.

The meter is not showing correct values or nothing at all:

- Check if the power supply is connected.
- Check that the power supply uses the correct voltage.
- Check that there is an output signal, at least 4 mA.
- Check the flow in the piping system and that is it enough to create the needed Δρ See section **7 Specifications**.
- Check that the Control Unit is mounted correctly with respect to the flow direction. Check that the arrow outside of the Pipe Section correspond with the actual flow direction. Check the flow direction selector under the Control Unit. Make sure that it corresponds to the actual flow.
- Check that the orifice calculation conditions correspond with the pressure and temperature of the system.
- Check that the orifice plate is correct for the application. Check the stamped values on the orifice plate and that it corresponds with Pipe Section, model number and flow.
- If compression couplings into the Control Unit inlet are used, check that the inside diameter is enough to avoid the bottle neck effect Check the table for the minimum correct inner diameter. (See section 2.3 Specifications)
- Verify that the inner diameter is correct and there are enough straight runs up-stream and downstream of the Pipe Section.

Media is coming out of the Control Unit:

Close the shut-off valves, disconnect the cables and let the system cool down. Remove the Control Unit and check that the Pipe Section and Control Unit have no cracks, and that all seals are undamaged.

The unit is damaged and shall be replaced.

Check the identification plate/tag on the Control Unit and note the serial number, flow range and liquid before ordering a new Control Unit from Eletta or a representative. The broken Control Unit can be changed in minutes without any on-site calibration. (See section **2.5 for details on how to replace a Control Unit**).

If the meters does not show the right value contact a local distributor or Eletta Service department for control.



15.2 Spare parts

See section **17 "Drawings"** for exploded drawings showing all replaceable components. If Eletta Steam is installed in a very critical application, it is recommended to have a complete, identically pre-calibrated Control Unit in stock, as it only involves four bolts to replace it. The Pipe Section seldom needs replacement since it does not consist of any moving parts but can also be ordered as spare part.

The Control Unit contains no exchangeable parts.

Do not try to repair the Control Unit. It is not possible to replace certain spare parts since the Control Unit must be calibrated as a whole. Contact a local distributor or Eletta Flow for advice and information about service.

The product label specifies the serial number, the flow range and the media.



16.1 Differential Pressure Range 1-10

M310- Dp-range: 5-500 mbar, Max. pressure: 10 bar

	-2%	10	+2%	-2%	20	+2%	-2%	30	+2%	-2%	40	+2%	-2%	50	+2%	-2%	60	+2%	-2%	70	+2%	-2%	80	+2%	-2%	90	+2%	-2%	100	+2%
%	8	10	12	18	20	22	28	30	32	38	40	42	48	50	52	58	60	62	68	70	72	78	80	82	88	90	92	98	100	102
mbar	3	5	7	16	20	24	39	45	51	72	80	88	115	125	135	168	180	192	231	245	259	304	320	336	387	405	423	480	500	520
mA	5,3	5,6	5,9	6,9	7,2	7,5	8,5	8,8	9,1	10,1	10,4	10,7	11,7	12,0	12,3	13,3	13,6	13,9	14,9	15,2	15,5	16,5	16,8	17,1	18,1	18,4	18,7	19,7	20,0	20,3

M325- Dp-range: 12,5-1250 mbar, Max. pressure: 25 bar

	-2%	10	+2%	-2%	20	+2%	-2%	30	+2%	-2%	40	+2%	-2%	50	+2%	-2%	60	+2%	-2%	70	+2%	-2%	80	+2%	-2%	90	+2%	-2%	100	+2%
%	8	10	12	18	20	22	28	30	32	38	40	42	48	50	52	58	60	62	68	70	72	78	80	82	88	90	92	98	100	102
mbar	8	13	18	41	50	61	98	113	128	181	200	221	288	313	338	421	450	481	578	613	648	761	800	841	968	1013	1058	1201	1250	1301
mA	5,3	5,6	5,9	6,9	7,2	7,5	8,5	8,8	9,1	10,1	10,4	10,7	11,7	12,0	12,3	13,3	13,6	13,9	14,9	15,2	15,5	16,5	16,8	17,1	18,1	18,4	18,7	19,7	20,0	20,3

16.2 Flow Ranges

		Dime	ensior	ning o	f stea	m lin	es (ca	apaci	ty in k	kg/h) l	ine din	nensio	n		
Pressure	Speed	15	20	25	32	40	50	65	80	100	125	150	200	250	300
ba r	m/s	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm	mm
	15	7	14	24	37	52	99	145	213	394	648	917	1606	2590	3678
0.4	25	10	25	40	62	92	162	265	384	675	972	1457	2806	4101	5936
	40	17	35	64	102	142	265	403	576	1037	1670	2303	4318	6909	9500
	15	7	16	25	40	59	109	166	250	431	680	1006	1708	2791	3852
0.7	25	12	25	45	72	100	182	287	430	716	1145	1575	2816	4629	6204
	40	18	37	68	106	167	298	428	630	1108	1712	2417	4532	7251	10323
	15	8	17	29	43	65	112	182	260	470	694	1020	1864	2814	4045
1.0	25	12	26	48	72	100	193	300	445	730	1160	1660	3099	4869	6751
	40	19	39	71	112	172	311	465	640	1150	1800	2500	4815	7333	10370
	15	12	25	45	70	100	182	280	410	715	1125	1580	2814	4545	6277
2.0	25	19	43	70	112	162	295	428	656	1215	1755	2520	4815	7425	10575
	40	30	64	115	178	275	475	745	1010	1895	2925	4175	7678	11997	16796
	15	16	37	60	93	127	245	385	535	925	1505	2040	3983	6217	8743
3.0	25	26	56	100	152	225	425	632	910	1580	2480	3440	6779	10269	14316
	40	41	87	157	250	357	595	1025	1460	2540	4050	5940	10476	16470	22950
	15	19	42	70	108	156	281	432	635	1166	1685	2460	4618	7121	10358
4.0	25	30	63	115	180	270	450	742	1080	1980	2925	4225	7866	12225	17304
	40	49	116	197	295	456	796	1247	1825	3120	4940	7050	12661	19663	27816
	15	22	49	87	128	187	352	526	770	1295	2105	2835	5548	8586	11947
5.0	25	36	81	135	211	308	548	885	1265	2110	3540	5150	8865	14268	20051
	40	59	131	225	338	495	855	1350	1890	3510	5400	7870	13761	23205	32244
	15	26	59	105	153	225	425	632	925	1555	2525	3400	6654	10297	14328
6.0	25	43	97	162	253	370	658	1065	1520	2530	4250	6175	10629	17108	24042
	40	71	157	270	405	595	1025	1620	2270	4210	6475	9445	16515	27849	38697
	15	29	63	110	165	260	445	705	952	1815	2765	3990	7390	12015	16096
7.0	25	49	114	190	288	450	785	1205	1750	3025	4815	6900	12288	19377	27080
	40	76	177	303	455	690	1210	1865	2520	4585	7560	10880	19141	30978	43470
	15	32	70	126	190	285	475	800	1125	1990	3025	4540	8042	12625	17728
8.0	25	54	122	205	320	465	810	1260	1870	3240	5220	7120	13140	21600	33210
	40	84	192	327	510	730	1370	2065	3120	5135	8395	12470	21247	33669	46858
	15	41	95	155	250	372	626	1012	1465	2495	3995	5860	9994	16172	22713
10.0	25	66	145	257	405	562	990	1530	2205	3825	6295	8995	15966	25860	35890
	40	104	216	408	615	910	1635	2545	3600	6230	9880	14390	26621	41011	57560
	15	50	121	205	310	465	810	1270	1870	3220	5215	7390	12921	20538	29016
14.0	25	85	195	331	520	740	1375	2080	3120	5200	8500	12560	21720	34139	47128
	40	126	305	555	825	1210	2195	3425	4735	8510	13050	18630	35548	54883	76534



16.3 Weight and Dimensions

Eletta Steam Unit	5,3kg
Control Unit M310 Plastic cover	0,4kg
Control Unit M310 Stainless steel cover	0,5kg
User Interface	1,4kg
Pipe Section	See table



Base Unit Steam





Additional dimensions for connection block





FSS DIN											
FSS DIN	ØD	ØD	Α	В	Е	F	Approx. Weight [kg]				
FSS15 (1/2")	17	53	114	140	1,5	15	0.5				
FSS20 (3/4")	22	63	120	152	1,5	15	0.6				
FSS25 (1")	29	73	127	163	3	15	0.7				
FSS32 (1 1/4")	39	84	133	175	3	15	0.8				
FSS40 (1 1/2")	43	94	139	186	3	15	1.0				
FSS50 (2")	55	109	147	201	3	15	1.2				
FSS65 (2 1/2")	70	129	157	222	3	15	1.5				
FSS80 (3")	82	144	165	237	3	15	1.7				
FSS100 (4")	107	164	176	258	3	15	2.0				
FSS125 (5")	132	194	191	288	3	15	2.5				
FSS150 (6")	160	219	213	323	3	15	3.0				
FSS200 (8")	207	274	241	379	3	15	4.2				
FSS250 (10")	260	330	269	435	3	15	5.6				
FSS300 (12")	310	385	297	490	3	15	7.1				
FSS350 (14")	340	445	327	550	3	15	10.4				
FSS400 (16")	390	498	373	621	3	18	14.1				
FSS450 (18")	441	557	403	681	3	18	17.3				
FSS500 (20")	492	619	434	743	3	18	21.1				



FSS ANSI											
FSS DN	Ød	ØD	Α	В	E	F	Approx. Weight [kg]				
FSS15 (1/2")	16	46	115	138	1,5	15	0,5				
FSS20 (3/4")	21	56	118	146	1,5	15	0,5				
FSS25 (1")	27	66	120	153	3	15	0,6				
FSS32 (1 1/4")	35	75	128	165	3	15	0,7				
FSS40 (1 1/2")	41	85	134	176	3	15	0,8				
FSS50 (2")	53	104	144	196	3	15	1,1				
FSS65 (2 1/2")	63	123	154	216	3	15	1,4				
FSS80 (3")	78	135	160	228	3	15	1,6				
FSS100 (4")	102	173	180	267	3	15	2,4				
FSS125 (5")	128	196	201	299	3	15	2,7				
FSS150 (6")	154	221	214	324	3	15	3,2				
FSS200 (8")	203	278	243	382	3	15	4,5				
FSS250 (10")	255	339	273	443	3	15	6,3				
FSS300 (12")	303	408	308	512	3	15	9,2				
FSS350 (14")	333	450	349	574	3	15	11,2				
FSS400 (16")	381	513	381	637	3	18	16,6				
FSS450 (18")	429	548	398	672	3	18	17,1				
FSS500 (20")	478	605	427	729	3	18	20,4				





GSS DIN and ANSI										
Description	С	Ød	Approx. Weight [kg]							
Pipe section GSS15 DIN	G 1/2	16	1.0							
Pipe section GSS20 DIN	G 3/4	21	0.5							
Pipe section GSS25 DIN	G 1	26	0.5							
Pipe section GSS15 ANSI	NPT 1/2	21	1.0							
Pipe section GSS20 ANSI	NPT 3/4	27	0.9							
Pipe section GSS25 ANSI	NPT 1	26	0.8							

Ţ



17.1 Eletta Steam

3-D models in STEP format are available at www.eletta.com





Eletta Steam			
26	Decal standard	Polyester	1
25	Flow direction selector FPM	FPM/316L (1.4404)	1
24	Screw MC6S A4-80 ISO 4762 M6x25	A4 316 (EN1.4401)	2
23	Block pipe shut off Steam	1.4436 (SS2343)	1
22	Block control unit Steam	1.4436 (SS2343)	1
21	Block condensate Steam	1.4436 (SS2343)	1
20	Angle bracket	316 (1.4401)	1
19	Shut off valve	316L (1.4404)	2
18	O-ring 8x1 FPM	FPM	2
17	Flow Direction arrow GL/FA	Aluminum	1
16	Screw ECS A4 DIN 84 ISO 1207 M3x6	A4 316 (EN1.4401)	1
15	Air valve SS	316L (1.4404)	4
14	O-ring 8.1x1.6 FPM	FPM	8
13	Fitting 6/4 SS	316L (1.4404)	8
12	Screw MKFX A2 DIN 966 M5x16	A2 304 (EN1.4301)	4
11	Screw MFT A4 ISO 14581 M5x12	A4 316 (EN1.4401)	6
10	Washer BRB A2 6,4x12x1,6	A2 304 (EN1.4301)	4
9	Screw MC6S A2-80 DIN 912 M6x12	A2 304 (EN1.4301)	4
8	Pipe 6/4 Steam	316 (1.4401)	2
7	O-ring 7.3x2.4 FPM	FPM	4
6	Screw MC6S A4-70 ISO 4762 M8x25	A4 316 (EN1.4401)	2
5.6	R-237 DN25 G1"	316L (1.4404)	2
5.5	R-237 DN25 G1". Machined G1/8"	316L (1.4404)	2
5.4	R-221 T-pipe DN25	1,4408	2
5.3	R-237 DN25 G1". Machined d=5 mm	316L (1.4404)	2
5.2	Attachment bracket	316L (1.4404)	1
5.1	O-ring 29.2x3 FPM	FPM	2
5	V1-S15C		1
4	Yoke condensate pot	316L (1.4404)	2
3	Bracket condensate pot	316L (1.4404)	2
2	Distance steam plate	316L (1.4404)	2
1	Assembly plate S15C	316 (1.4401)	1
ITEM NO.	DESCRIPTION		QTY.





Eletta Steam Pipe Sections				
3.8	Spacer GSS 15-25	316L (1.4404)	1	
3.7	O-ring 29.2x3, FPM, Green	FPM	1	
3.6	Orifice plate GL15-25	Complete pipe-section	1	
3.5	Nut M6M A2 ISO 4032 M8	A2 AISI 304,	4	
3.4	Screw M6S A4-80 ISO	A2 AISI 304,	4	
3.3	O-ring 39.2x3, FPM Green	FPM	2	
3.2	Thread Connecting Flange GSS 25	EN 1.4470 (EN 10213)	2	
3.1	Connecting pipe GSS15-25	EN 1.4470	1	
3	Complete pipe-section GSS25		1	
2.6	O-ring 49.5x3, FPM	FPM	1	
2.5	Screw MFX A2 DIN 965 M3x10	A2 AISI 304, EN1.4301	2	
2.4	DN 15-500 Flange gasket	Tensnit BA-U	2	
2.3	FSS40 Weld assy replacable orifice DIN	316L (1.4404)	1	
2.2	Spacer FSS15-400	316L (1.4404)	1	
2.1	FA/FSS40 Orifice plate	316L (1.4404)	1	
2	FSS40 Assy with replaceable orifice		1	
1	Screw MC6S A4-70 ISO 4762 M8x25	A4 AISI 316, EN1.4401	2	
ITEM NO.	DESCRIPTION	Material	QTY.	



Recycle the product and reuse/recycle the packaging.

These products and packaging should not be mixed with general household waste. For proper recycling, take these products to a designated collection point.

Contact local authority for further details of the nearest designated collection station.

Correct product disposal and reusing of the packaging material saves resources and prevents negative effects on human health and the environment.



If you have questions, considerations or suggestions for improvements that would enhance your business, we will be happy to hear from you.



+46 8 603 07 70 Switchboard +46 8 603 07 80 Orders and Inquires E-mail: <u>info@eletta.com</u>

